

JOLD-70-QPXF-1L

# Fiber-coupled diode lasers: qcw, passively cooled with integrated TEC

Design 215415124

#### Features

- High optical output power 70 W qcw
- Wavelengths: 808 and 938 nm
- Fiber core diameter: 600 μm (NA 0.22)
- Integrated power monitor
- Long Lifetime > 20,000 h, high reliability

### **Applications**

- Pumping of solid-state lasers and fiber lasers
- Material processing
- Medical applications

## Fiber-coupled diode lasers | qcw, passively cooled with integrated TEC JOLD-70-QPXF-1L

Specifications (start of life)	JOLD-70-QPXF-1L Design 215415124	
Operation Mode	qcw	
Maximum Pulse Length/Duty Cycle	≤ 0.3 ms/≤ 20 %	
Maximum Optical Output Power	70 70	W
Center Wavelength at 25 °C	808 938	nm
Center Wavelength Variation at 25 °C	5 5	nm
Typical Spectral Bandwidth (FWHM)	3 3	nm
Maximum Spectral Bandwidth (FWHM)	5 5	nm
Typical Operation Current	105 120	A
Maximum Operation Current	120 130	A
Typical Threshold Current	18 20	A
Maximum Threshold Current	20 25	A
Typical Slope	0.8 0.7	W/A
Minimum Slope	0.7 0.65	W/A
Maximum Operating Voltage	2.2 2.2	V
Fiber Core Diameter, Numerical Aperture	600 μm, NA 0.22 free standing fiber inside F-SMA 905 towards the module	
Fiber Connector	F-SMA 905	
Power Monitor	Infineon, SFH 229	
Anode, Cathode Connectors	M5 (e.g. socket cap screw ISO 4762), M4 (threaded bolt and hex nut ISO 4032)	
Operation Conditions	Non-condensing atmosphere	
Expected Lifetime	> 1 GShot	
Cooling		
Mounting	Via thermally conductive foil (thickness 25 100 µm) on cooled surface	
Note	Do not mount via any paste-like media!	
Diode Laser Operating Temperature	15 30 °C, measured with internal temperature sensor	
Temperature Sensor	PT 100 and PT 1000	
Integrated TECs	Connected in series, cold side at max. 30 °C	
Maximum Cooling Power	2 TECs x 173 W => 346 W	
Maximum TEC Voltage, Current	2 x 24.6 V => 49.2 V, 11.3 A	
	Manufactured under license of FhG-ILT Aachen (Germany).	

#### See general user information!

Options on request: For additional designs or specifications please visit our website: www.jenoptik.com





